

Index		
PARAMETER	DESCRIPTION	Pg. No.
	Features	4
	Items Included.	5
	Key Introduction	6
	Fault Messages.	7
	LED Indication.	8
	Parameter List.	9
SET POINT	To set the cut-out point of the controller.	9
QFS	To set the quick freeze set point.	9
EXIT	End of set mode	9
	To set other parameter	9
P2	To set allowable high temperature limit.	10
P3	To set allowable low temperature limit.	10
P4	To set the differential for compressor restart.	10
P5	To set probe calibration.	11
P6	To set time delay between relay restart time.	11
P7	To set duration of defrost.	12
P8	To set defrost frequency.	12
P9	To set power on defrost delay.	12
P10	To set type of defrost.	13
P11	To set drip time for defrost.	13
P12	To set type of computation for defrost time.	13
P13	To set Defrost Stop Temperature at Time based.	14
P13	To set Defrost Stop Temperature at Temperature based.	14
P14	To set Mode to Start Defrost.	14
P15	To set Defrost Start Temperature.	15

Index		
PARAMETER	DESCRIPTION	Pg. No.
P16	To set Defrost Start Temperature Delay.	15
DI-D	To select AUX or compressor thermal trip digital I/P	16
OPS	To Enable / Disable Oil Pressure Switch (OPS) I/P.	16
QFD	To set quick freeze duration.	16
CND6	To set condenser on delay time.	17
CND7	To set condenser status at hot gas defrost.	17
L1	To set Evaporator Fan stop temperature.	17
L2	To set Evaporator Restart Delay.	17
L3	To set Evaporator Fan status at compressor off.	18
L4	To set Evaporator Fan differential.	18
L5	To set Evaporator probe calibration.	18
L7	To set Evaporator Fan status at Door open condition.	18
L8	To set Evap Fan status during defrost.	19
BUZ	To enable / disable buzzer.	19
AL	Alarm Relay Enable / Disable.	19
ADT	HT Power ON alarm delay.	19
ADD	Alarm/Buzzer output delay at Door open	20
THD	Temperature Hold Duration at Door open	20
C-UL	Under load limit for compressor current.	20
C-OL	Over load limit for compressor current.	21
C2	Current sensing delay.	21
D0	To enable or Disable HP sensing.	21
D1	To enable or disable LP sensing.	22

Index		
PARAMETER	DESCRIPTION	Pg. No.
D2	Fault sensing logic.	22
D3	To set LP sensing delay.	22
D4	To set reset mode for HP fault.	23
E1	To set Compressor Relay status on Probe Failure.	23
TON	To set On cycle at room probe fail.	23
TOFF	To set Off cycle at room probe fail.	24
E7	To set Display at defrosting.	24
E8	Defrost duration during Coil probe failure.	24
LD	To set time delay to switch off the light .	24
LSD	Light ON at Door open	25
PDN	To activate Solenoid Valve relay.	25
PW	To change password.	26
CRH	To view Compressor run Hours.	26
CCRH	Clear Compressor Run Hours.	26
ID	To set Unit ID.	26
BAUD	To set Unit Baud Rate.	26
LP	To activate Keypad Lock.	27
PO	To enable/disable Power Switch.	27
PDIS	To set display at power OFF mode.	27
FS	To restore default settings of the controller.	28
EP	End of programming.	28
	Technical Data	29
	Instruction Manual for LVM VMRC-10/3	30-37
	Suggested Wiring Diagram	38
	Caution & Warranty	39-40

Features:


This controller controls the defrost in the system based on either an electrical heater where the compressor is stopped, or at cycle inversion using warm gas where the compressor keeps on working.

There are safety features which include shutting down the system incase of a fault from a pressure control or similar device.

A series of “safety controls” (delay at start-up, minimum disable time, minimum time between activation) protects the compressors from close starts. In case of probe error or temperature alarm, the instrument signals the event through acoustic signal and by closing the relay contact. By pressing the mute key, the buzzer is silenced.

A number of parameters are displayed alphanumerically to set up the instrument for each specific function.











Computer Connectivity over RS485 and Remote monitoring (Optional).

Single Operation Quick Freeze Mode(Press  key for 2 sec), set system in quick freeze mode which is time based for that period new set point will be lower than running set point and system will try to achieve that set point, after time period over set point will be normal set point.

Items included

NO.	ITEMS	QTY
1.	CONTROLLER	1
2.	NTC SENSOR 5 METER	2
3.	CATALOGUE	1
4.	8 X 38 SCREW WITH RAWL PLUG	4











Key Introduction



	Used to enter in manual defrost and to stop defrost if defrosting is ON.
	Used to increment / scroll UP in Program Mode. When not in any mode if this key is pressed for 2 secs controller will enter in display Probe mode where Evap temperature can be viewed.
	Used to come mute the buzzer/Alarm & to exit any mode.
	Used to enter in fault log mode.
	Used to switch OFF/ON the controller.
	Used to enter in quick freeze mode.
	Used to decrement / scroll down in Program mode. Used to enter into the program mode.
	Used to enter into the Set mode. Also used as enter key if controller is in Set mode/program mode. Also used to save changed value.
	Used to enter in display Amp. mode where compressor current can be viewed.
	Used to switch OFF/ON the light.



Fault Messages :

Ht	High temperature alarm for Room temperature means, room temperature is equal or above the set value of P2 parameter.
Lt	Low temperature alarm for Room temperature means, room temperature is equal or below the set value of P3 parameter.
PP	Room temperature fail means, Room sensor not connected or out of range.
E-PP	Evaporator temperature fail means, Evaporator sensor not connected or out of range.
DO	Door Input Fault.
SPPR	SPPR Fault.
C-OL	Compressor over load fault.
C-UL	Compressor under load fault.
HP	HP fault.
LP	LP fault.
AUX/CTH	Auxiliary fault / Compressor Thermal Fault .
OPS	Oil Pressure Switch Fault.
C-PD	Compressor switched ON for Pump down in manual defrost

LED Indication

Messages	Mode	Discription
	ON OFF Flashing	Comp. Relay ON. Comp. Relay OFF. Comp. Relay Time delay.
	ON OFF	Cond. Relay ON. Cond. Relay OFF.
	ON OFF Flashing	Evap. Relay ON. Evap. Relay OFF. Evap. Relay Time delay.
	ON OFF Flashing	Defrost Relay ON. Defrost Relay OFF. Defrost Relay Time delay.
	ON OFF	LSV Relay ON. LSV Relay OFF.
	ON OFF	Alarm Relay ON. Alarm Relay OFF.
	Flashing	Controller is in drip time.
	ON OFF	Controller is in quick freeze mode. Controller is not in quick freeze mode.
	OFF ON	Power OFF. Power ON.
	ON OFF	Light Relay ON. Light Relay OFF.
R	ON OFF	R-phase present. R-phase absent.
Y	ON OFF	Y-phase present. Y-phase absent.
B	ON OFF	B-phase present. B-phase absent.

Min: MINIMUM Max : MAXIMUM Fact. Set : FACTORY SETTING(DEFAULT)		
Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
SET MODE		
To set other parameter Press & hold SET key for 2 seconds		Display will show 'SP' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys. After desired value, press the SET key & you will see "----" which confirms that the parameter value has been stored in memory.
		
01	SP	To set the cut-out point of the controller.
To change Set Point parameter, press the set key.		Display will change to set value. The set point value can now be changed by using the UP/DOWN key.
Range		
Min	Max	Fact. Set
QFS+0.5	P2-0.5°C	-20.0°C
QFS = Quick Freeze Set Point		
02	QFS	To set the quick freeze set point.
To change QFS parameter, press the set key.		Use UP/DOWN keys to set desired value.
If controller is in quick freeze mode then compressor will cut in/ cut out as per this set point till the quick freeze duration is over.		
SP : Set Point.		
Range		
Min	Max	Fact. Set
P3+0.5	SP-0.5	-25.0°C
03	EXIT	End of set mode
PROGRAM MODE		
To set other parameter Press & hold PRG key for 2 seconds		Display will show '0000'. Set correct password to enter into program mode. The display will show 'P2' and scroll the description of the parameter. To go to other parameters, use UP / DOWN keys. After desired value, press the SET key & you will see "----" which confirms that the parameter value has been stored in memory.
		

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
01	P2 Parameter	Function : To set allowable high temperature limit.	
To change P2 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go above this value and below P3 setting.	
Range			
Min	Max	Fact. Set	
SP+0.5°C	50.0°C	50.0°C	
 (Message on Display)			
02	P3 Parameter	Function : To set allowable low temperature limit.	
To change P3 parameter, press the set key.		Use UP/DOWN key to set desired value. Once set at a particular value, this will not allow the set point to go below this value and above P2 setting.	
Range			
Min	Max	Fact. Set	
-40.0°C	QFS-0.5°C	-40.0°C	
 (Message on Display)			
03	P4 Parameter	Function : To set the differential for compressor restart.	
To change P4 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Example(Cooling Mode) : If the set point is set at 10.0°C and differential is set at 2.0°C, then when the system reaches 10.0°C, the comp. relay will cutout. Since the differential is 2.0°C, the comp. Relay will cutin at 12.0°C (10.0°C + 2.0°C).			
Range			
Min	Max	Fact. Set	
0.5°C	20.0°C	2.0°C	

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
04	P5 Parameter	Function : To set room probe calibration.		
To change P5 parameter, press the set key.		Use UP/DOWN keys to set desired value. In time it may be possible that the display may be offset by a degree or so.		
Range		To compensate this error, you may need to add or minus the degrees required to achieve the correct temperature.		
Min	Max			Fact. Set
-10.0°C	10.0°C			0.0°C
		Example : The temperature on the display is 28.0°C, whereas the actual temperature is 30.0°C. You may need to set this parameter to 2.0°C, which means that once out of the programming parameter, the display will show the temperature 30.0°C (28.0°C + 2.0°C).		
05	P6 Parameter	Function : To set time delay between compressor relay restart time.		
To change P6 parameter, press the set key.		Use UP/DOWN keys to set desired value. This parameter is used to protect the fan from restarting in a short period of time and can be set between 0 to 20 minutes.		
Range		Example : If this parameter is set at 3 minutes, once compressor will cut off at the set temperature, it will not restart for a minimum of 3 minutes, even if the differential is achieved earlier. This parameter is good to protect the life of the compressor when there are power fluctuations and the compressor is switched off and on within a few seconds.		
Min	Max			Fact. Set
1 Min	20 Min			3 Min

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
06	P7 Parameter	Function : To set duration of defrost.		
To change the P7 parameter, press the set key.		Use UP/DOWN keys to set desired value.		
Range		This is maximum amount of time allowed for defrost. If set to 0, there will be no defrost cycle.		
Min	Max			Fact. Set
0 Min	99 Min			30 Min
		Example : If P7 is set to 15 Mins and P8 parameter is set to 1 Hr. then after every 1 Hr defrosting will take place for 15 mins.		
07	P8 Parameter	Function : To set defrost frequency.		
To change the P8 parameter, press the set key.		Use UP/DOWN keys to set desired value. This is the amount of time between two defrost cycles.		
Range		Example : same as P7 parameter.		
Min	Max			Fact. Set
1 Hr	31 Hrs			6 Hr
08	P9 Parameter	Function : To set power on defrost delay.		
To change the P9 parameter, press the set key.		Use UP/DOWN keys to set desired value. This is the amount of time at power on after which defrosting will take place once.		
Range		If this parameter is set to 0, there will be no power ON defrost.		
Min	Max			Fact. Set
0 Min	99 Min			0 Min
		Example : If P9 parameter is 30 mins then at power after 30 mins defrosting will take place once.		

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	P10 Parameter	Function : To set type of defrost.	
	To change the P10 Parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		HTR : Heater defrost where compressor is OFF.
	Min	Max	Fact. Set
	HTR	HTG	HTR
		HTG : Hot Gas defrost where compressor is ON.	
10	P11 Parameter	Function : To set drip time for defrost.	
	To change the P11 Parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		During this period Compressor, Evaporator Fan, LSV relay and Heater will stay OFF so that the defrost water can drain out.
	Min	Max	Fact. Set
	0 Min	30 Min	1 Min
11	P12 Parameter	Function : To set type of computation for defrost time..	
	To change the P12 Parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		REAL = Total of real time.
	Min	Max	Fact. Set
	REAL	CRH	REAL
		Example : This means that the time calculation for defrost frequency will be for the total hours the unit has been running. CRH - Sum of total compressor operating times. This means that for time calculation, the unit will add the total time the compressor has been in an ON mode. It keeps a record of the hours worked +/-½ Hour in case of a power failure. Example : If Defrost frequency is set to 6hrs. and 3.45 hrs have passed after unit has started and power fails, then defrost cycle will start after 3½ hours when power resumes.	

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
12	P13 Parameter	Function : To set Defrost Stop Temperature at Time based.		
	To change the P13 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	when P14 = TIME		If coil/Evap temperature is reached upto this temperature defrost will stop.	
	Range		Example : If this parameter is set to 4.0°C, then if defrosting is in progress then when temperature reaches 4.0°C, the defrost process will stop.	
Min	Max	Fact. Set		
	-40.0°C	50.0°C	4.0°C	
when P14 = TEMP				
Range				
Min	Max	Fact. Set		
	P15+1.0	50.0°C	4.0°C	
14	P14 Parameter	Function : To set Mode to start the Defrost.		
	To change the P14 Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		When set to,	
	Min	Max	Fact. Set	
	TIME	TEMP	TIME	
		TIME : Defrost will start on Time based as per P8 Parameter. TEMP : Defrost will start on Time or Temperature, whichever takes first to start Defrost.		
		Note : when P14 Parameter set to TEMP, P13, P15 & P16 parameters reset to Factory settings. P15, P16 parameters will be visible only when P14 set to TEMP.		

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
15	P15 Parameter	Function : To set Defrost start Temperature.		
	To change the P15 Parameter , press the set key.		Use UP/DOWN keys to set desired value.	
	Range			Defrost process will start when Coil Temperature is less than or equal to P15 for P16 parameter settings.
	Min	Max	Fact. Set	
-40.0°C	P13-1.0	-28.0°C	When Defrost stop condition occurs due to P7 duration over or Defrost stop manually then it will check Coil Temperature should be greater than or equal to P15+1.0.	
		<p>Example: If P15 set to -28.0°C & P16 is set to 10Min, then when Coil Temperature reaches to or goes below -28.0°C for 10Min, the Defrost process will start.</p> <p>If Defrost stop condition occurs that time, Temperature should be greater than or equal to -27.0°C.</p> <p>Note: This Parameter is visible only when P14 is set to TEMP.</p>		
16	P16 Parameter	Function : To set Defrost Start Temperature Delay.		
	To change the P16 Parameter , press the set key.		Use UP/DOWN keys to set desired value.	
	Range			When Coil Temperature is less than or equal to P15 parameter, Defrost will Start After P16 duration.
	Min	Max	Fact. Set	
0 Min	99Min	10 Min	Example: same as P15 parameter	
		<p>Note: This Parameter is visible only when P14 is set to TEMP.</p>		

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
17	DI-D Parameter	Function : To select AUX or compressor thermal trip digital I/P		
	To change the DI-D Parameter , press the set key.		Use UP/DOWN keys to set desired value.	
	Range			If Selected as "AUX" then at fault it will display "AUX" on display.
	Min	Max	Fact. Set	
AUX	CTH	CTH	If Selected as "CTH" then at fault it will display "CTH".	
18	OPS Parameter	Function : To Enable / Disable OPS I/P.		
	To change the OPS Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			ENB : OPS I/P is enabled. DIS : OPS I/P is disabled.
	Min	Max	Fact. Set	
DIS	ENB	ENB		
19	QFD Parameter	Function : To set quick freeze duration.		
	To change the QFD Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range			This is the maximum amount of time allowed for Quick Freeze. If set to "0", there will be no quick freeze.
	Min	Max	Fact. Set	
0 Hr	12 Hrs	2 Hr	Example : If QFS is set to -20.0°C, and quick freeze duration is set to 1 hr ,then when it is in quick freeze mode, then the Comp. will work on -20.0°C set point for 1hr.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
20	CND6 Parameter	Function : To set condenser ON delay timings.	
		To change the CND6 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	0 Sec	30 Sec	15 Sec
21	CND7 Parameter	Function : To set condenser status at hot gas defrost.	
		To change the CND7 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	OFF	ON	OFF
22	L1 Parameter	Function : To set Evaporator Fan stop temperature.	
		To change the L1 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	-40.0°C	50.0°C	2.0°C
23	L2 Parameter	Function : To set Evaporator Restart Delay.	
		To change the L2 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	0 Min	20 Min	1 Min

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
24	L3 Parameter	Function : To set Evaporator Fan status at compressor off.	
		To change the L3 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	OFF	ON	ON
25	L4 Parameter	Function : To set Evaporator Fan differential.	
		To change the L4 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	0.5°C	20.0°C	2.0°C
26	L5 Parameter	Function : To set Evaporator probe calibration.	
		To change the L5 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	-10.0°C	10.0°C	0.0°C
27	L7 Parameter	Function : To set Compressor-Evaporator Fan status at Door open condition.	
		To change the L7 parameter, press the set key.	
	Range		
	Min	Max	Fact. Set
	NORM	F-C	NORM

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
28	L8 Parameter	Function : To set Evaporator Fan status during defrost.	
	To change the L8 parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		OFF : Evaporator Fan OFF during defrost.
	Min	Max	Fact. Set
	OFF	ON	OFF
29	BUZ Parameter	Function : To enable / disable buzzer.	
	To change the BUZ parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example: ENB : Buzzer enabled. DIS : Buzzer disabled.
	Min	Max	Fact. Set
	DIS	ENB	ENB
30	AL Parameter	Function : This parameter is used to Enable / Disable alarm relay.	
	To change the AL Parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		DIS : To deactivate Alarm Relay in fault condition.
	Min	Max	Fact. Set
	DIS	ENB	ENB
31	ADT Parameter	Function : This parameter is used to set HT power on delay for alarm.	
	To change the ADT parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example : If you set this parameter to 20, once the power is switched on, the HT alarm will not activate for 20 minutes after the power is switched on. This is most useful to avoid the nuisance alarms when the ambients are high when the machine is switched on after a long time.
	Min	Max	Fact. Set
	0 Min	99 Min	30 Min

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
32	ADD Parameter	Function : This parameter is used for time delay to activate Alarm/Buzzer relay at Door Open.	
	To change the ADD parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example : This Parameter is set to 60 Sec & Door is open then Alarm/Buzzer will be ON after 60sec, if AL & BUZ parameters are enabled.
	Min	Max	Fact. Set
	0 sec	600 sec	60 sec
33	THD Parameter	Function : This parameter is used to set duration for temperature hold at door open.	
	To change the THD parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example : This Parameter is set to 60sec, Room Temperature is -18.0°C & Door open condition occurs then Room Temp value -18.0°C at Door open condition will be hold for the 60sec, if Room Temperature is increasing. After over the Temperature hold duration display temperature will be increased by 0.1°C at every sec until it reaches current Room Temperature.
	Min	Max	Fact. Set
	0 sec	180 sec	0 sec
34	C-UL Parameter	Function : Under load limit for compressor current.	
	To change the C-UL parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example : If C-UL= 1.0A and compressor current is less than 1.0A then and exists till C2 current sensing delay then it is registered as UL fault. Compressor will get OFF on this fault. If after 3 retries within 1 Hour current drawn is still less than 1.0Amp the controller will trip the compressor on fault and activate respective alarm relay. Also display will flash 'C-UL'. Controller will go in manual reset mode.
	Min	Max	Fact. Set
	0.0A	(C-OL -1.0)A	1.0A

Description of parameters and functions.				
Sr. No.	Parameter	Parameter setting method		
35	C-OL Parameter	Function : Over load limit for compressor current.		
	To change the C-OL parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Controller with 20A CT		Example : If C-OL= 15.0 A and compressor current is greater than 15.0 A then and exist till C2 current sensing delay then C-OL fault exists and flash on display. Compressor will be tripped on this fault.	
	Range			
	Min	Max		Fact. Set
	(C-UL +1.0) A	20.0A	15.0A	
Controller with 50A CT		NOTE: 20/50A CT option available while ordering controller.		
Range				
Min	Max		Fact. Set	
(C-UL +1.0) A	50.0A	30.0A		
36	C2 Parameter	Function : Current sensing time delay.		
	To change the C2 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example : If C2 = 5 sec then, any current fault will be valid only when it exists for more than 5 sec.	
	Min	Max		Fact. Set
5 Sec	120 Sec	5 Sec		
37	D0 Parameter	Function : To enable or Disable HP sensing.		
	To change the D0 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
	Range		Example : If this parameter is set to ENB : HP sensing is enabled. DIS : HP sensing is disabled. Setting this parameter to disable will ignore HP fault for compressor. If this parameter is set to Enable then controller will detect HP trip.	
	Min	Max		Fact. Set
	DIS	ENB		ENB



Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
38	D1 Parameter	Function : To enable or disable LP sensing.	
	To change D1 parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example: If this parameter is set to ENB : LP sensing is enabled. DIS : LP sensing is disabled. Setting this parameter to disable will ignore LP fault for compressor. If this parameter is set to Enable then controller will detect LP trip.
	Min	Max	
DIS	ENB	ENB	
39	D2 Parameter	Function : Fault sensing logic.	
	To change D2 parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		0V : 0V at HP/LP/AUX input will be sensed as fault and trip the compressor. 230V : 230V at HP/LP/AUX input will be sensed as fault and trip the compressor.
	Min	Max	
0V	230V	0V	
40	D3 Parameter	Function : To set LP sensing delay.	
	To change D3 parameter, press the set key.		Use UP/DOWN keys to set desired value.
	Range		Example : If this parameter is set to 5 sec, then LP fault will be sensed only when it present continuously for 5 Secs.
	Min	Max	
0 Sec	180 Sec	30 Sec	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
41	D4 Parameter	Function : To set reset mode for HP fault.	
To change D4 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		MAN : Manual Mode. AUTO : Auto mode.	
Min	Max	Fact. Set	
MAN	AUTO	AUTO	
		If this parameter set to "MAN" mode HP fault will be cleared only after pressing reset key for 2 seconds. If this parameter is set to "AUTO" mode HP fault will be cleared automatically when it is healthy.	
42	E1 Parameter	Function : To set Compressor Relay status on Probe Failure.	
To change E1 parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		When set to ON : Relay will stay ON. CYC : Relay performs a duty cycle of as per TON & TOFF . OFF : Relay will stay OFF.	
Min	Max	Fact. Set	
ON	OFF	CYC	
43	TON Parameter	Function : To set ON cycle time for compressor at room probe fail.	
To change TON parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		At room probe fail condition when E1 parameter is selected as 'CYC' then the ON cycle is specified by TON parameter.	
Min	Max	Fact. Set	
1 Min	30 Min	10 Min	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
44	TOFF Parameter	Function : To set OFF cycle time for compressor at room probe fail.	
To change TOFF parameter, press the set key.		Use UP/DOWN keys to set desired value. At room probe fail condition when E1 parameter is selected as 'CYC' then the OFF cycle is specified by TOFF parameter.	
Range			
Min	Max	Fact. Set	
1 Min	30 Min	4 Min	
45	E7 Parameter	Function : To set Display at defrosting.	
To change E7 parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range		TEMP : During defrost, temperature will be displayed. DEFR : During defrost, 'Defrost ON' will scroll. RHLD : During Defrost, Display Holds Room Temperature. Display Room temp. will update after Defrost/Drip time, when it goes below or equal to Hold Temperature.	
Min	Max	Fact. Set	
TEMP	DEFR	TEMP	
Note : Control Unit action will be as per Real Temperature.			
46	E8 Parameter	Function : Defrost duration during Coil probe failure.	
To change E8 parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range		Example: If this is set to 10 min, then manual defrost for 10 min will take place during Coil probe fail.	
Min	Max	Fact. Set	
1 Min	15 Min	5 Min	
47	LD Parameter	Function : To set time delay to switch off the light .	
To change LD parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range		This parameter is used set the time delay to automatically switch OFF the light. If LD is set to 0 then this parameter is disabled.	
Min	Max	Fact. Set	
0 Min	30 Min	7 Min	
Example : If this parameter is set to 7 mins then, when light is switched ON, after 7 mins it will be switch OFF automatically.			

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
48	LSD Parameter	<p>Function : This parameter is used to enable / disable light relay ON at door open.</p> <p>To change LSD parameter, press the SET key.</p> <p>Use UP/DOWN keys to set desired value. If this parameter is set to Enable then whenever Door get open, the Light Relay will be ON.</p> <p>If this parameter is set to Disable then Light Relay will be ON/OFF functioning manually and as per LD parameter.</p>	
Range			
Min	Max	Fact. Set	
DIS	ENB	ENB	
49	PDN Parameter	<p>Function : To activate Solenoid Valve relay.</p> <p>To change PDN parameter, press the set key.</p> <p>Use UP/DOWN keys to set desired value. DIS : Pump down disable and SV relay will active only with Compressor except Hotgas defrost.</p> <p>ETMP : Pump down enable at Set point when compressor tripped on Set Point.</p> <p>EDEF : Pump down enable at Set point when heater defrost condition occurs.</p> <p>Example : ETMP : If this parameter is set to ETMP then SV relay will be ON/FF & pump down at Set point. EDEF : If this parameter is set to EDEF then SV relay will be ON/OFF on SP & pump down only at heater defrost condition.</p>	
Range			
Min	Max	Fact. Set	
DIS	EDEF	DIS	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
50	PW Parameter	<p>Function : To change password.</p> <p>To change the PW parameter, press the set key.</p> <p>Use UP/DOWN key to change the password.</p> <p>User can enter into program mode only if correct password is entered. If the password is wrong it will show 'INVALID PASSWORD'.</p>	
Range			
Min	Max	Fact. Set	
0	9999	0	
51	CRH Parameter	<p>Function : To view Compressor run Hours.</p> <p>It will display compressor run hours. It's a read only parameter.</p>	
52	CCRH	<p>Function : Clear Compressor Run Hours.</p> <p>If this parameter is set to 'YES' compressor run hours (CRH) are cleared.</p>	
Range			
Min	Max	Fact. Set	
NO	YES	NO	
53	ID Parameter	<p>Function : To set Device ID.</p> <p>To change Device ID parameter, press the SET key.</p> <p>This parameter is used to set the Device ID for the controller.</p>	
Range			
Min	Max	Fact. Set	
1	240	-	
54	BAUD Parameter	<p>Function : To set Baud Rate for MODBUS Communication.</p> <p>To change BAUD parameter, press the SET key.</p> <p>When set to, 9.6 = 9600 19.2 = 19200 38.4 = 38400 57.6 = 57600</p>	
Range			
Min	Max	Fact. Set	
9.6	57.6	-	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
55	LP Parameter	Function : To activate Keypad Lock.	
To change Keypad Lock parameter, press the set key.		This parameter can lock the keypad so that tempering is not possible by by-standers.	
Range			
Min	Max	Fact. Set	
NO	YES	NO	
		NO : deactivates keypad lock. YES : activates keypad lock.	
		On activation, all the parameters can only be viewed, but not modified. If the keypad is locked "LOCK" message will be displayed.	
56	PO Parameter	Function : To enable/disable Power Switch.	
To change PO parameter, press the SET key.		Use UP/DOWN keys to get desired value & press SET key to confirm.	
Range			
Min	Max	Fact. Set	
DIS	ENB	DIS	
		DIS : Disable power switch ENB : Enables power switch	
		Controller has power switch, which if enable puts controller in active or stand by state. If  key press for 2 seconds controller will go in stand by mode, display will be as per "PDIS" parameter. To again switch to ACTIVE WORKING MODE, press power switch again for 2 seconds. All leds and display will flash and enter into NORMAL WORKING MODE.	
57	PDIS Parameter	Function : To set display at power OFF mode.	
To change PDIS parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
LED	TEMP	LED	
		At power OFF mode power OFF LED will glow & display will be as below, LED : Display Will be Blank. OFF : Display will show OFF. TEMP : Display will show Temperature.	

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
58	FS Parameter	Function : To restore default settings of the controller.	
To change FS parameter, press the SET key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
NO	YES	NO	
		When set to YES all parameters are programmed to factory values. Useful to debug setting related problems.	
59	EP Parameter	Function: To exit from program mode.	
To exit programming parameter, press the SET key.		Once the set key is pressed, the controller goes into the normal mode and displays the Room Temperature and all settings are recorded.	

Technical Data

Housing	: Plastic / Sheet Metal (as per customer requirement)
Dimensions	: Plastic : (H)400 x (W) 300 x (D)135 mm : Sheet Metal : (H)450 x (W) 400 x (D)200 mm
Mounting	: Wall mounting.
Controller	: CRC-2052
Connection	: Spring clamp terminal block. 4 sq. mm wire.
Display	: 4 Digit, 1" Dot matrix Display and 13 LEDs for indication.
Data Storage	: Non-Volatile EEPROM Memory.
Power Input (Options)	: 415Vac +/-10%, 50-60Hz. 3Phase Supply with Neutral
Operating Temp	: 5°C to 50°C(non-condensing).
Storage temp	: -20°C to 70°C(non-condensing).
Output	:
Compressor Relay	: 5A/230vac
Defrost Relay	: 5A/230vac
Evap. Relay	: 5A/230vac
Condenser Relay	: 10A/230vac
Light Relay	: 5A/230vac
Alarm Relay	: 5A/230vac
LSV Relay	: 10A/230vac
Sensors :	
1) Temperature sensor:	
Sensor Type	: NTC Thermistor.
Resolution	: 0.1°C.
Accuracy	: +/-1°C.
Probe Tolerance at 25°C	: +/-0.3°C.
Room & Evap Temperature :	
Range	: -50.0°C to 50.0°C
Analog I/p:	
Compressor current (R,Y,B)	
Resolution	: 0.1Amp.
Accuracy	: +/-1 Amp.
Digital Inputs:	
HP, LP, Auxiliary / CTH(Compressor Thermal) , Oil Pressure Switch(OPS), Door, SPPR, R-Ph, Y-Ph, B- Ph.	
Buzzer	: Internal
RS485 Connectivity	: Modbus RTU Protocol Baud Rate : 9600 (Settable) Device ID : 1 (By Default)

Instruction Manual

LVM (Line Voltage Monitor) Three Phase VMRC-10/3

Index


PARAMETER	DESCRIPTION	Pg. No.
	Introduction	29
	Get to know your Controller.	29
	To set program mode.	30
<i>rEF</i>	To set Reference Voltage.	30
<i>oU</i>	To set Over voltage Limits.	30
<i>uU</i>	To set Undervoltage Limits.	31
<i>unb</i>	To set Un Balance Value.	31
<i>ttd</i>	To set Time Delay.	31
<i>tdr</i>	To set fault recover delay.	32
<i>CrY</i>	To set Calibration of Voltage.	32
<i>Crb</i>	To set Calibration of Voltage.	32
<i>Crb</i>	To set Calibration of Voltage.	33
<i>dSP</i>	To set Display mode.	33
<i>FS</i>	To Restore factory defaults.	33
<i>End</i>	End programming.	34
	Technical Data.	35
	Front View & Connection Diagram.	35

Introduction

VMRC-10/3 is three phase Line voltage monitor (LVM) used to protect device from Single Phasing, voltage unbalance, phase reversal and under/over voltage. It shows real time voltages between phase and neutral.

There is an Output of alarm relay is given to the controller as SPPR input. Features are easily understood by examples in the instruction below.

Get to Know Your Controller



Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
To set other parameter			
Press & hold PRG key for 4 seconds PRG SET		Display will show 'rEF' and scroll the description of the parameter. To go to other parameters, use up / down keys.	
01	<i>rEF</i> PARAMETER	Function : To set Reference voltage.	
To change the rEF Parameter, press the set key.		Use UP/DOWN keys to set desired value. Base reference voltage to calculate under voltage and over voltage values.	
Range			
Min	Max	Fact. Set	
381V	415V	415V	
Min and Max value will change according to display type for settings. Example : If dsP is L-L then Min= 381V, Max=415V.			
02	<i>oV</i> PARAMETER	Function : To set Overvoltage Limits.	
To change the oV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes above this limit will trip respective a/c on Overvoltage("Ov") fault.	
Range			
Min	Max	Fact. Set	
5V	75V	35V	
Example : Over voltage is calculated depending on Reference voltage + Ov value. i.e. Ov Set Point = Ref + Ov , When controller trip on Ov Fault it will recover when input voltage fall below (Ref - (Ov /2).			

Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
03	<i>uV</i> PARAMETER	Function : To set Undervoltage Limits.	
To change the uV parameter, press the set key.		Use UP/DOWN keys to set desired value. If the a/c voltages goes below this limit will trip respective a/c on undervoltage("Uv") fault.	
Range			
Min	Max	Fact. Set	
5V	75V	35V	
Example : Under voltage is calculated depending on Reference voltage - Uv value. i.e Uv Set Point = Ref - Uv , When controller trip on Uv Fault it will recover when input voltage above (Ref – (Uv /2).			
04	<i>unb</i> PARAMETER	Function : To set Un Balance value.	
To change the unb parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
10V	120V	60V	
Unbalance fault raised when voltage difference between any of two phases goes above Unb value and recovers when the difference is less than (UNB/2).			
05	<i>ttD</i> PARAMETER	Function : To set time delay.	
To change the ttd parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range			
Min	Max	Fact. Set	
0Sec	60Sec	10Sec	
Time delay provided to avoid false triggering, when any fault last more than TTD value then only fault is raised and this fault is applicable to Under voltage, Over voltage and Unbalance fault.(i.e., In case of Phase Loss or Phase sequence fault alarm will come immediately).			


Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
06	<i>t_{dr}</i> PARAMETER	Function : To set fault recover delay.	
To change the t _{dr} parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		Time delay provided to add delay in fault recover time, to avoid sudden fault triggering and reset.	
Min	Max	Fact. Set	
0Sec	240Sec	10Sec	
07	<i>C_{rY}</i> PARAMETER	Function : To set calibration of voltage for r-y or r-n phase.	
To change the CrY Parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-y. When dsP is L-n then it sets calibration for r-n.	
08	<i>C_{yb}</i> PARAMETER	Function : To set calibration of voltage for y-b or y-n phase.	
To change the Cyb parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for y-b. When dsP is L-n then it sets calibration for y-n.	


Description of parameters and functions.			
Sr. No.	Parameter	Parameter setting method	
09	<i>C_{rb}</i> PARAMETER	Function : To set calibration of voltage for r-b or b-n phase.	
To change the C _{rb} parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		This parameter provided to calibration voltage reading.	
Min	Max	Fact. Set	
-15V	15V	0V	
		When dsP is L-L then it sets calibration for r-b. When dsP is L-n then it sets calibration for b-n.	
10	<i>d_{SP}</i> PARAMETER	Function : To set view display mode.	
To change the dsP parameter, press the set key.		Use UP/DOWN keys to set desired value.	
Range		There are two type of display output, Line to Line Voltage (L-L) and Line to Neutral (L-n), Depending on this parameter REF parameter also changes.	
Min	Max	Fact. Set	
L-L	L-n	L-L	
11	<i>F_S</i> PARAMETER	Function : To restore the default settings of the controller.	
To change the FS parameter, press the set key.		Use UP/DOWN keys to set desired value. When set to 1, all parameters are programmed to factory values.	
Range			
Min	Max	Fact. Set	
nO	YES	nO	

Description of parameters and functions.		
Sr. No.	Parameter	Parameter setting method
12	End PARAMETER	Function :To end programming.
	To change the end parameter, press the set key.	Once the set key is pressed, the controller goes into the normal mode and displays the voltage readings.

Technical Data

- Main Functions :** Voltage Monitoring.
Phase Sequence Monitoring.
Phase Loss and Phase Unbalance detection.
Uv and Ov Detection.
Settable Uv and Ov Parameter.
- Dimensions :** Front : 70mm X 45mm,
Depth : 72.3 mm
- Input :** R, Y, B Phases and Neutral Input.
- Output :** Alarm Relay : 5A Resistive.
- Application :** :Voltage and phase sequence monitoring and controlling.
Under voltage and Over voltage detection.
- General Specification :**
Input Voltage Range from 100VAC to 265VAC.
- Mounting :** : Din rail mounting.
- Connections :** : Screw terminals : $\leq 2.5\text{sqmm}$ one wire/terminal only.





SUGGESTED CONNECTOR STICKER

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41		
R	Y	B	N					+	-	R	Y	B	R	Y	B	N	R	Y	B	L	N	L	N	C	N	C	N	L	N	L	N	OUT	IN	OUT	IN	HP / LP OUT	HP IN	LP IN	LP IN	GND	IN	↑
MAIN INCOMING SUPPLY				ROOM PROBE		COIL PROBE		RS485		COMPRESSOR				EVAPORATOR				DEFROST				CONDENSER		LSV		LIGHT		ALARM		FRAME HEATER		CCH		OIL PRESSURE SWITCH		AUX. / CTH		HP / LP OUT		DOOR		

Controller

Controller should be installed in a place protected by vibration, water and corrosive gasses and where ambient temperature does not exceed the values specified in the technical data.

Probe

To give a correct reading, the probe must be installed in a place protected from thermal influences, which may affect the temperature to be controlled.

Caution

WIRING : The probe and its corresponding wires should never be installed in a conduit next to control or power supply lines. The electrical wiring should be done as shown in the diagram. The power supply circuit should be connected to a protection switch.

WARNING : Improper wiring may cause irreparable damage and personal injury. Kindly ensure that wiring is done by qualified personnel only.

Maintenance : Cleaning : Clean the surface of the controller with a soft moist cloth. Do not use abrasive detergents, petrol, alcohol or solvents.

Notice

The information in this document is subject to change in order to improve reliability, design or function without prior notice and does not represent a commitment on the part of the company. In no event will the company be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

Disclaimer

These manual & its contents remain the sole property of PVR CONTROLS, India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparation of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company. PVR CONTROLS, reserves the right to make and changes or improvements without prior notice.

Warranty

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, including lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS



INDIA

Cold Room Controller

Chiller Controller

Two Compressors Controller

Heating Controller

Humidity Controller

Pressure Controller

The logo for CASTLE, featuring the brand name in a bold, uppercase, sans-serif font with a registered trademark symbol (®) to the upper right.

Ball Valves

Globe Valves

Hand Valves

Flow Switches

Solenoid Valves